

Unilever Professional

Handy Andy Professional Floor Degreaser And Cleaner (5 L)



Dirty and greasy floors? No problem. Safely remove grease and food stains on floors in just 10 seconds** with the new Handy Andy Professional Floor Degreaser and Cleaner - a powerful degreaser that leaves floors clean and shiny with no need to rinse.

No need to rinse and suitable for use on multiple floor surfaces, Handy Andy Professional Floor Degreaser and Cleaner leaves floors sparkling clean.

Keep your business spotlessly clean with Handy Andy Professional Floor Degreaser and Cleaner.

Benefits

- · Clean and shiny floors in 10 seconds**
- · Powerful grease and food stain removal
- No need to rinse
- · Deeply removes difficult grease

Areas of application

- Kitchen floors
- Tiles
- Painted surfaces







Caution

 On marble, enamel bathtubs, painted surfaces, painted wood, plastics and linoleum use diluted product only and rinse immediately after use to avoid damage. Do not use on untreated wood. For natural stones or new and unusual surfaces test first on a small inconspicuous area. Do not mix with other cleaning products.

How to use

Dilute Usage:

Pour 100 ml of Handy Andy Floor Degreaser and Cleaner in 5 L of water.

Step 2

Clean and wipe with the diluted mixture. For shinier results, wipe with a dry cloth.

Neat Usage:

Pour on a wet sponge or directly on the surface.

Clean and wipe clean. For shinier results, wipe with a dry cloth.



*Food Safe indicates that the product is safe to use on food preparation areas if usage instructions on back of pack are followed. This is supported by the certification provided by Intertek, an external company that performed the analysis o Toxicological Safety for Use in Direct Food Contact Applications (SANS 1828).