





Better Clean **Better Business**

Stubborn kitchen grease? NO PROBLEM







Safely and quickly dissolve stubborn grease and dirt with the new food safe* Handy Andy Professional Multipurpose Degreaser - a naturally-derived cleaning agent that leaves a streak-free shine.



NEW

FOOD SAFE*

MULTIPURPOSE **DEGREASER**





Unilever Professional

Handy Andy Professional Multipurpose Degreaser (5 L)



Stubborn kitchen grease? No problem. Safely and quickly dissolve stubborn grease and dirt with the new food safe* Handy Andy Professional Multipurpose Degreaser – a naturally-derived cleaning agent that leaves a streak-free shine.

Easy to rinse and suitable for use on multiple surfaces, Handy Andy Professional Multipurpose Degreaser is highly effective on daily kitchen dirt, degreases quickly & easily, and leaves your food preparation surfaces sparkling clean.

Keep your kitchen surfaces spotlessly clean with Handy Andy Professional Multipurpose Degreaser.

Benefits

- Quickly dissolves grease, dirt and oil splashes
- · Naturally-derived cleaning agent
- · Streak-free shine
- · Food safe*

Areas of application

- Stove tops
- Kitchen surfaces
- Food preparation surfaces







Caution

- Always use on cold surfaces.
- Avoid prolonged contact with painted surfaces.
- Do not use on painted wood, anodized aluminium, marble and linoleum.
- Do not use on appliance lettering and symbols.
- For new or unusual types of surfaces, test on a small inconspicuous area first.
- · Do not mix with other cleaning products.

How to use

Step 1

Decant into a smaller spray bottle.

Step 2

Spray onto the surface.

Step 3

Leave for a few seconds and wipe with a cloth. For tough dirt leave for a few minutes before wiping clean.

